# UV-C Air Purifier Heater & Fan | EFB-PCTH



Please read these instructions and warranty information carefully before use and keep them handy for future reference.

Online Warranty Registration



USER MANUAL



請即進行保用登記!

有關保用條款細則,請看本説明書最後一頁。

Please register your warranty information now!

For Warranty Terms & Conditions,

please refer to the last page of this user manual.

## Contents

Warnings & Safety Instructions	4
Product Structure	6
Getting Started	7
Operating Instructions	9
Cleaning & Maintenance	15
Technical Specification	18
Warranty Terms & Conditions	35

P.2

## Warnings & Safety Instructions

## **!** WARNING!

To avoid fire, electric shock, and injury, you must meet the following requirements. Otherwise, please follow the respective national and local electricity regulations.


- 1. This product is only suitable for indoor use and should not be used outdoors.
- 2. Non-professional personnel or unauthorized repair personnel may not repair or modify this product by themselves.
- 3. Before plugging in the power supply, please check that the rated voltage matches the voltage in your home.
- 4. Keep at least 1.5 meters away from fire source or tinder, and avoid direct sunlight.
- DO NOT use this product near objects that are flammable, explosive, subject to heat, deformation, discoloration or deterioration. DO NOT use this product in places with severe dust.
- DO NOT use this product underneath hanging objects that may be prone to fall down. DO NOT use this product in places that are vulnerable to shocks. DO NOT place this product on unstable surfaces.
- 7. DO NOT turn the product on/off by pulling or inserting the plug. Always turn product on/off by using the product's ON/OFF button.
- DO NOT use this product as heat preservation and heating equipment for animals and plants.
- DO NOT place any objects on the air inlet or outlet to avoid overheating the product.
- DO NOT insert metal wire or any other foreign objects into any crevices of this
  product to avoid electric shock.
- DO NOT use this product if it has been dropped or if it shows any sign of damage.
- 12. DO NOT immerse this product in water.
- DO NOT use this product directly facing an electrical outlet or under a power outlet.
- 14. DO NOT let this product share the socket with other high-power appliances.

## Warnings & Safety Instructions

- 15. DO NOT directly pull the power cord to move the body.
- 16. If this product is covered or incorrectly placed, it can cause a fire hazard. Therefore, DO NOT use a programmable automatic power-on device, timer, or any other device with this product.
- 17. When this product is in use, the power cord should be placed behind the body. Placing the power cord in front will cause it to overheat and be damaged, or even cause an accident.
- 18. Children, elderly people or patients who have lost the ability to take care of themselves, please use this appliance under the supervision of an adult to prevent accidents.
- 19. If this product fails, please turn off the power and unplug the power cord immediately. This product must only be repaired by the manufacturer's maintenance department or a similarly qualified professional.
- 20. Before use, check that the power cord and the plug are in good condition. If the power cord is damaged, in order to avoid danger, the user MUST NOT disassemble or replace it. Replacing the power cord must only be performed by the manufacturer's maintenance department or a similarly qualified professional.
- 21. To avoid getting burnt when using this product, please DO NOT let bare skin come into direct contact with the surface of the air outlet.
- 22. This product is only suitable for use in dry environment. Do not use around a bathtub, sprinkler or swimming pool.
- 23. If there is a gap between the plug and the socket, or the plug has become very hot, it may be necessary to replace the socket. Consult a qualified electrician to replace the socket.
- 24. This product must be connected to a fixed (wall) socket compatible to the specified capacity and in compliance with the current industry standards.

## **Product Structure**

#### **Body**




- 1. Air Duct
- 2. Air Outlet
- 3. LED Display
- 4. Top Cover
- 5. Air Inlet
- 6. Base

- 7. Air Duct
- 8. Top Cover
- 9. Air Inlet
- 10. Body
- 11. Power Cord

## **Getting Started**

#### Location

- 1. Please put this product on a level surface. Avoid putting it on an unstable surface (such as a slanted or soft surface) to prevent it from falling over. Please do not use it in hot and humid areas (such as bathroom and kitchen).
- 2. Avoid blocking the Air Inlet and Air Outlet when product is in use. Please keep the product far away from curtains, so that they will not block the Inlet/Outlet and obstruct the product from working properly.
- 3. DO NOT place objects within 1 meter in front of the Air Outlet to ensure that the air flow would not be reduced.



## **Getting Started**

#### **Battery Replacement**

- 1. To open the battery cover at the bottom of the Remote Control, press the buckle on the battery cover inward and pull it out.
- 2. Identify the polarity of the battery, and insert the battery into the battery slot.
- 3. Reinsert the battery cover into the bottom of the Remote Control.










#### Attention:

- 1. If Remote Control will not be used for a prolonged period of time, please remove the battery.
- 2. This battery is not rechargeable. DO NOT recharge the battery.
- 3. The Remote Control and battery are not toys. Please keep them out of children's reach.
- 4. If accidentally swallow battery, please seek medical attention immediately.

## **Operating Instructions**

#### **Main Body**



#### Air Duct Angle Setting

Before adjusting the air duct angle, please make sure the product is turned off. Hold product body with one hand and set the air duct 15° forward or backward.

#### Switch ON and OFF


- 1. Connect to power source, and product will enter into Standby Mode.
- 2. Press On/Off (1), the buzzer will beep once, and product will start to operate.
- 3. To turn off the product, long-press (1) 2 seconds, the buzzer will beep once, and product will stop operating.

#### Attention:

- When operating in Warm Air Mode, the air duct will become hot. Shortly
  after the product is turned off, it may still be hot to the touch. Please be
  cautious.
- This product has a built-in Overheat Protection Sensor, which is an automatic fail-proof safety protection that cuts off power automatically when the product is accidentally tipped over or overheats. If this sensor is triggered and the product is stopped, unplug the product and let it cool down.

# **Operating Instructions**

## **LED Display**




# **Operating Instructions**

## **LED Display Icon**

Icon	Description
Ú	<ul> <li>On/Off Button</li> <li>Press () to turn product on.</li> <li>Press () repeatedly to adjust air volume.</li> <li>Long-press () 1 second to turn Oscillation on and off.</li> <li>Long-press () 2 seconds to turn off product.</li> <li>Long-press () 5 seconds to connect product to smartphone App Control.</li> </ul>
	Filter Replacement Alert Indicator Light  After a total of 720 hours of operation, will light up, indicating the filter needs to be replaced. After the filter has been replaced, long-press on the Remote Control for 5 seconds, will turn off, and product will enter a new 720 hour cycle.
<b>₩</b>	UV-C Disinfection Indicator Light When UV-C Disinfection Function is turned on via the Remote Control, www. will light up. UV-C will automatically turn off after 1 hour.
(·	Wi-Fi Indicator Light  Long-press (¹) on the LED Display for 5 seconds,
88 <sub>c</sub>	Temperature Display In Cool Air Mode, display will light up in blue; in Warm Air Mode, display will light up in orange.
88%	Settings & Humidity Display This indicates the current setting and humidity level.

## **Operating Instructions**

#### **Remote Control**



### Attention:

- 1. The Remote Control should be pointed directly at the Signal Receiver on the Display Panel to maximize remote control reception.
- 2. This product may respond to the remote control of other devices.
- 3. Other products may respond to this Remote Control. This is due to overlapping frequencies of the remote controls. There is no quality problem in the product itself. To avoid interference, keep this Remote Control away from other electrical devices during operation.
- 4. The On/Off button on the Remote Control does not completely disconnect the power supply to this product. If product will be unused for a prolonged period of time, please unplug the power cord from the socket.

## **Operating Instructions**

#### **Remote Control Functions**

Function	Button	Description
On/Off	Ů	<ul> <li>In Standby Mode, press once to turn on product.</li> <li>When product is operating, press once and product will turn off and return to Standby Mode.</li> </ul>
UV-C Sterilization	UV-C	<ul> <li>Press once to turn on UV-C Sterilization Function.</li> <li>Press again to turn off UV-C Sterilization Function (Otherwise, UV Sterilization Function will automatically turn off after operating for 1 hr).</li> </ul>
Oscillation	v	<ul> <li>Press once to turn on Oscillation Function, oscillation angle is 80°±5°.</li> <li>Press again to turn off Oscillation Function.</li> </ul>
Timer Mode	•	Press this button to set Countdown To Turn Off Time (1-8 hr). When countdown completes, the product will automatically stop operating.  If user wishes to restart product, please press ().
Sleep Mode	၁	Press once to enter Sleep Mode; LED Display will show "LL", and airflow will decrease to the lowest level. Press again to exit Sleep Mode.
	(A)	<ul> <li>Press once to switch to Warm Air Mode.</li> <li>In Warm Air Mode, LED Display lights up in orange.</li> </ul>
Warm Air Mode	+ \( \rangle \)	<ul> <li>In Warm Air Mode, press +/- to adjust temperature from 1-30°C.</li> <li>In Cool Air Mode, this button does not respond.</li> </ul>
	+ %	Press + to increase airflow; press - to decrease airflow. Warm Air Mode has 4 levels of airflow.
Cool Air	<b>%</b>	<ul> <li>Press once to switch to Cool Air Mode.</li> <li>In Cool Air Mode, LED Display lights up in blue.</li> </ul>
Mode +		<ul> <li>Press + to increase airflow; press - to decrease airflow.</li> <li>Cool Air Mode has 9 levels of airflow.</li> </ul>

## **Operating Instructions**

#### **Thermostat Function Instruction (Warm Air Mode)**

- 1. Press the "Warm Air Mode" button and the LED Display shows the ambient temperature.
- 2. Press "+ %-"button, temperature display on LED Display will flash, and user can set A desired temperature (1-30°C).
- 3. 10 seconds after the desired temperature is set, LED Display will stop flashing, and show ambient temperature.
  - The temperature being set should be higher than the ambient temperature, so that the heating function will be turned on.
  - When the ambient temperature reaches the set temperature, the heating function will stop, the product will continue to run for 40 seconds, then return to Standby Mode.
  - When ambient temperature drops lower than the set temperature, the heating function will automatically be reactivated.

#### Attention:


- The factory default temperature is set at 25 °C.
- After the Warm Air Mode has run for over 9 hours, the product will automatically stop running. Restart by pressing the On/Off Button on the main body or the Remote Control.

## Cleaning & Maintenance




#### **WARNING!**


Unplug the power supply before performing maintenance.




#### **Filter Replacement**




1. Lift out Top Cover.



2. Lift out the old air filter.



3. Install new filter into the main body of the product.



4. Reinstall Top Cover, the magnetic lid will snap into place automatically.

P.14


## Cleaning & Maintenance


#### **Product Surface**

- When cleaning the product, do not wet or splash water on the product, to avoid water entering inside and causing malfunction.
- Do not use banana oil, benzine, alcohol, bleach or metal objects to wipe the surface of the product, which may damage the surface or cause discoloration.
- Please use soft dry cloth to lightly wipe the surface of the product.
- If the surface is very dirty, use a soft cloth and diluted mild detergent to clean, then wipe dry with a soft dry cloth.

#### Air Inlet & Air Outlet

Use a soft brush or vacuum cleaner to regularly clean off any dust accumulated on the Air Inlet and Outlet. Do not let dust build up as too much dust will reduce the efficiency of the product.





## Cleaning & Maintenance

#### **Remote Control**

Gently wipe the surface of the Remote Control with a soft dry cloth. If the Remote Control will not be used for a prolonged period of time, please remove the battery inside to avoid battery consumption.



#### **Power Plug**

Use soft dry cloth to clean the power plug.



#### **Storage**

- After cleaning the product, put in plastic bag and store away.
- Please avoid storing in a place with vibration (car trunk) or a place heated or cooled by another appliance.
- Please avoid placing it in direct sunlight or in a hot and humid environment.
- Please keep this product out of reach of young children.

P.16

# **Technical Specification**

Model	FEB-PCTH
Rated Voltage/Frequency	220V - 240V~ / 50Hz - 60Hz
Rated Power	45W (Fan) / 2000W (Heat)
Product Dimensions	(H)700 (W)255 (D)255 mm
Net Weight	Approx. 5 kg
Gross Weight	Approx. 6 kg

Specifications are subject to change without prior notice.

If there is any inconsistency or ambiguity between the English version and the Chinese version, the Chinese version shall prevail.

Refer to www.germanpool.com for the most up-to-date version of the Operating Instructions.

# 目錄

警告及注意事項	20
產品結構	22
使用前的準備	23
操作説明	24
清潔與保養	31
技術規格	34
保用條款	35

## $\Lambda$

#### 警告!

為避免火災、電擊、人身傷害,請務必遵守以下要求;其他請遵循國家 及地區的有關電氣法規。

- 1. 本產品只適宜室內使用,不宜在室外使用。
- 2. 非專職人員或者未授權修理人員,不得自行修理或改造本機。
- 3. 插接電源前,請檢查本產品標明的額定電壓是否與您家中的電壓相符。
- 4. 機器正常使用或閒置時,離火源和火種1.5米以上,並避免陽光直射。
- 禁止在易燃、易爆、受熱易變形、變色、變質的物體附近使用,禁止在有嚴重粉 塵的地方使用。
- 6. 禁止在有易落下懸掛物的地方使用,禁止在易受衝擊或擺放在不穩定的地方使用。
- 7. 禁止用插(拔)電源線插頭的方法代替功率開關的開機和關機。
- 8. 禁止把本機作為動植物的保溫、加熱設備。
- 9. 為避免過熱,禁止覆蓋加熱器。
- 10. 嚴禁用細的金屬絲或其他異物插入機內任何孔隙,以免造成觸電事故。
- 11. 如果本產品跌落或有明顯的損壞跡象,請勿使用。
- 12. 嚴禁將機器浸入水中。
- 13. 嚴禁將機器對著電源插座或置於電源插座下使用。
- 14. 嚴禁本機與其他大功率電器共用插座。
- 15. 嚴禁直接拉著電源線移動機體。
- 16. 因為機器被覆蓋或不正確的放置會引起火災危險,故不得利用帶有可自動接通電源的程式器、定時器、或任何其他裝置來使用本產品。
- 17. 本產品在使用時電源線應置於機體後面,放在機體前面會使其過熱而損壞,甚至發生安全事故。

## 警告及注意事項

- 18. 小孩、喪失生活自理能力的老人或病人請在成人監護下使用本電器,以防發生 意外。
- 19. 若本產品出現故障,請立即關機並拔下電源線插頭,必須由製造商維修部或類似部門專業人員維修。
- 20. 使用前需要先檢查電源線以及插頭是否破損,如果電源軟線損壞,為了避免危險,用戶不得自行拆卸、更換電源線,必須由製造商其維修部或類似部門專業人員更換。
- 21. 使用本產品時,為避免灼燒,請不要讓裸露的皮膚直接接觸出風口表面。
- 22. 僅嫡合在乾燥環境下使用。在浴缸、噴頭或游泳池的四周不得使用本產品。
- 23. 如果插頭與插座之間出現鬆動或插頭變得很燙,可能需要更換插座。諮詢有資格的電工以更換插座。
- 24. 本產品必須配套與插頭額定工作電流一致的有認證的固定插座,嚴禁使用移動 多用插座。

# 1 7 2 3 4 8 5 9

OWCUMD HEPATS

- 1. 風圏
- 2. 出風口
- 3. LED 顯示屏
- 4. 濾網頂蓋
- 5. 進風口
- 6. 底座

- 7. 風圏
- 8. 濾網頂蓋


11

- 9. 進風口
- 10. 機身
- 11. 電源插頭

## 使用前的準備

#### 使用位置


- 1 請將本產品放置在水平位置使用,請不要放置在不穩定地方(如有斜度、柔軟的表面),以避免本產品翻倒造成損壞或故障。請不要在高溫多濕的地方使用 (如浴室、廚房)。
- 2 在使用過程中,需避免擋住進風口,請遠離裝有窗簾的地方使用以避免物體堵 住進風口導致本產品無法工作。
- 3 出風口前面1米內不要放置物體以減弱吹風效果。



## 操作説明

#### 安裝遙控器電池

- 1. 向內按住遙控器底部電池槽上的扣位,電池槽往外拉出。
- 2. 確認電池的極性,將電池裝進電池槽的凹槽內。
- 3. 將電池槽裝回遙控器的底部。










#### 注意:

- 1. 如果長時間不使用遙控器,請取出電池。
- 2. 此電池請勿充電。
- 3. 這不是玩具,請置於小孩接觸不到的地方。
- 4. 如誤吞電池,請立即求醫。

## 操作説明

#### 主機操作方法



#### 風圈角度調整

運行停止後,朝向喜歡的方向擺動;請單手按住主機,對風圈角度進行前後各15°調節。

#### 開關機操作


- · 連接電源, 打開電源開關, 進入待機狀態。
- ·按開關鍵(「),蜂鳴器提示聲響一聲,開始運行。
- ·運行過程中長按 ( ) 2 秒關機,蜂鳴器提示聲響一聲,停止運行。

#### 注意:

- 1. 暖風模式下風圈會發熱,使用後短時間內尚有餘熱,請注意高溫。
- 2. 為確保人身安全,本產品裝有自動斷電開關,可在本產品傾倒或過熱時 自動斷電,如果觸發此開關,請拔出電源插頭並使其冷卻。

# 操作説明

### LED顯示屏




P.26

## LED顯示屏圖標説明

圖標	説明
(h)	<b>開關鍵</b> <ul> <li>按 ( ) 開機。</li> <li>開機後重複按 ( ) 調整風量。</li> <li>長按 ( ) 1 秒開啟或停止左右搖擺功能。</li> <li>長按 ( ) 2 秒關機。</li> <li>長按 ( ) 5 秒進入手機應用程式連接狀態。</li> </ul>
	過濾網更換指示燈 本產品累計運行720小時後 前 常亮,表示需要更換過濾網; 更換過濾網後長按遙控器 () 5秒, 前 熄滅並重新累計時間。
<b>₩</b>	UV-C殺菌指示燈 透過遙控器啟用UV-C殺菌功能後 🏟 常亮;1小時後自動關閉。
<u>(</u> :	Wi-Fi連接指示燈 長按LED顯示屏 () 5秒, ○ 閃爍並進入手機應用程式連接狀態,再長按 () 5秒, ○ 快速閃爍進入相容模式,連接成功後 ○ 常亮。再長按LED顯示屏 () 5秒取消連接。
88%	<b>溫度顯示</b> 顯示溫度,涼風模式下以藍色顯示,暖風模式下以橙色顯示。
88%	<b>檔位及濕度顯示</b> 顯示當前檔位或濕度。

## 操作説明

#### 遙控器



## 注意:

- 1. 使用遙控器控作時,需將遙控器對準顯示屏的遙控信號接收器,使遙控 信號接收達到最好。
- 2. 使用其他電器的遙控器時,本產品可能會產生反應。
- 3. 使用本產品的遙控器時,其他電器可能會產生反應。這是由於遙控器的 頻率產生重疊而發生的現象,產品本身並無品質問題,為了避免誤操 作,操作時請將遙控器遠離其他電器。
- 4. 遙控器的開關鍵不能使本產品電源完全關閉,如果長時間不使用,請拔掉插頭。

#### 遙控器操作説明

功能	按鍵	功能説明	
開關	Ů	· 待機狀態下,按此鍵開始運行。 · 運行狀態下,按此鍵停止運行,返回待機狀態。	
UV-C 殺菌	UV-C	· 按此鍵開啟UV殺菌功能。 · 再按一次,關閉UV殺菌功能(UV殺菌功能開啟1小時後會自動關 閉)。	
搖擺	$\cup$	· 按此鍵開啟左右搖擺功能,搖擺角度為80°±5° · 再按一次,停止搖擺功能。	
定時	4	<ul><li>按此鍵可設定1至8小時定時關機功能,時間到機器會自動停止運行。</li><li>如需要重新開機請按()。</li></ul>	
睡眠 模式	<b>છ</b>	· 按此鍵進入睡眠模式,LED顯示屏顯示「LL」,風量變小。 · 再按一次,退出睡眠模式。	
	rp)	· 按此鍵調整為暖風模式。 · 暖風模式下LED顯示屏以橙色顯示。	
		· 暖風模式下按+/-鍵設定溫度為1-30℃。 · 涼風模式下按此鍵無效。	
	+ %	· 按+鍵,風量增強;按-鍵,風量減弱。 · 暖風模式下可進行4檔調節。	
<b>1</b>	<b>%</b>	· 按此鍵調整為涼風模式。 · 涼風模式下LED顯示屏以藍色顯示。	
涼風     模式	+ %	· 按+鍵,風量增強;按-鍵,風量減弱。 · 涼風模式下可進行9檔調節。	

#### 恆溫功能説明(暖風模式)

- 1. 按下暖風模式鍵,LED顯示屏顯示環境溫度。
- 2. 按溫度+ 冷-鍵, LED顯示屏溫閃爍, 顯示設定溫度, 可設定1-30℃。
- 3. 溫度設定好10秒後, LED顯示屏停止閃爍, 顯示環境溫度。
- · 設定溫度高於環境溫度,製熱功能開啟。
- ·環境溫度達到設定溫度,製熱功能停止,機器繼續運行40秒後停止運行,進入待機狀態。
- · 當環境溫度低於設定溫度,機器啟動運行並開啟製熱功能。

#### 注意:


- · 出廠預設溫度為25℃。
- · 暖風模式持續運行9小時後,機器會自動停止運行。重新開機按主機電源按鍵或用遙控器開啟。

## 清潔與保養




#### 警告!


進行保養時請一定要先拔下插頭切 斷電源。




#### 更換過濾網




1. 向上拿起濾網頂蓋。



2. 向上取出舊的過濾網。



3. 將新的過濾網放回主機內部。



4. 將濾網頂蓋放回主機並磁吸固定。


## 清潔與保養


#### 產品表面

- ·保養的時候,請不要讓產品沾上水或者潑上水,可能會導致機器進水而損壞。
- ·請勿使用天拿水、汽油、酒精、漂白劑或者金屬物體去擦拭風扇表面,可能會導致表面變色、變質。
- · 請用乾的軟布輕輕擦拭風扇表面。
- ·如果表面比較髒,可以用中性洗滌劑稀釋後用濕軟布擦拭,擦拭乾淨後再用乾軟 布進行擦拭。

#### 進風口及出風口

請用軟刷或吸塵器清潔進風口和出風口處的灰塵,集聚太多灰塵的話可能會影響使用效果,請在灰塵較少的時候及時進行清潔。





## 清潔與保養


#### 遙控器

請用乾的軟布輕輕擦拭遙控器表面。如果長時間不使用,避免電池消耗,請取出遙控器內的電池。



#### 電源插頭

請用乾的軟布清潔電源插頭。



#### 保管方法

- ·本產品保養後可以裝入塑膠袋並進行收藏。
- ·請避開震動的場所以及有製冷或製熱功能的電器。
- · 請避免放置在陽光直射,高溫潮濕的地方。
- · 請放置在幼兒碰不到的地方。

型號	FEB-PCTH
電壓/頻率	220V - 240V~ / 50Hz - 60Hz
額定總功率	45W (涼風) / 2000W (暖風)
機身尺寸	(H)700 (W)255 (D) 255 mm
淨重	約 5 kg
總重	約 6 kg

- 所有資料僅供參考,如有錯漏以廠方生產的規格為準。產品規格及設計如有變 更,恕不另行通知。
- 中英文版本如有出入,一概以中文版為準。
- 本產品使用説明書以www.germanpool.com網上版為最新版本。

## 保用條款

此保用提供德國寶產品之機件在正常使用下壹年保用 (自購買日起計算)。

## Warranty Terms & Conditions

Under normal operations, the product will be guranteed for one year, with full warranty provided by German Pool (effective from the date of purchase).

- \* 貴戶須在購機十天內,以下列其中一種方式向本公司 登記資料,保用手續方正式生效:
  - 1) 填妥本公司網頁內之 保用登記表格

www.germanpool.com/ warranty

2) 填妥保用登記卡, 郵寄至本公司。



- \* This warranty is not valid until customer registration information is received by our Service Centre within 10 days of purchase via one of the following means:
- 1) Visit our website and register online:

www.germanpool.com/ warranty

2) Complete all the fields on the attached Warranty Card and mail it back to our Customer Service Centre.



另請填妥以下表格並與正本發票一併保存,以便維修時核對資料。用戶提供之所有資料必須正確無誤,否則免費保用將會無效。 Please fill out the form below. This information and the original purchase invoice will be required for any repairs. Warranty will be invalid if information provided is found to be inaccurate.

型號 Model No.: **EFB-PCTH** 

機身號碼 Serial No.:

發票號碼 Invoice No.:

購買日期 Purchase Date:

購買商號 Purchased From:

- 1. 未能出示購買發票正本者,將不獲免費維修服務。
- 2. 用戶應依照説明書的指示操作。本保用並不包括:
  - 上門安裝、檢驗、維修或更換零件之人工以及 一切運輸費用;
  - 因天然與人為意外造成的損壞 (包括運輸及其他);
  - 電源接合不當、不依説明書而錯誤或疏忽使用本 機所引致之損壞。
- 3. 於下列情況下,用戶之保用資格將被取消:
- 購買發票有任何非認可之刪改;
- 產品被用作商業或工業用途;
- 產品經非認可之技術人員改裝或加裝任何配件;
- 機身編號被擅自塗改、破壞或刪除。
- 4. 總代理有權選擇維修或更換配件或其損壞部份。
- 5. 產品一經被轉讓,其保用即被視作無效。

 operating failures resulting from applying incorrect voltage, improper usage, and/or unauthorized installations

not be eligible for free warranty service.

material transfer and others);

2. Customer should always follow the operating instructions. This warranty does not apply to:

or repairs.

1. Customer who fails to present original purchase invoice will

- labour costs for on-site installation, check-up, repair,

replacement of parts and other transportation costs; - damages caused by accidents of any kind (including

- 3. This warranty is invalid if:
- the purchase invoice is modified by an unauthorized party;
- the product is used for any commercial or industrial purposes;
- the product is repaired or modified by unauthorized
- personnel, or unauthorized parts are installed; - the serial number is modified, damaged or removed from the product.
- 4. German Pool will, at its discretion, repair or replace any defective part.
- 5. This warranty will be void if there is any transfer of ownership from the original purchaser.

#### Customer Service & Repair Centre Hong Kong Macau

10/F, Kowloon Godown 3/F, Edificio Industrial Pou Fung,

1-3 Kai Hing Road, Kowloon Bay, 145 Rua de Francisco Xavier Pereira,

Kowloon, Hong Kong

Macau : +852 2333 6249 : +853 2875 2699

: +853 2875 2661

: +852 2356 9798 Email : repairs@germanpool.com

Fax

#### 客戶服務及維修中心 香港

九龍灣啟興道1-3號

澳門俾利喇街145號

九龍貨倉10樓

寶豐工業大廈3樓

電話: +853 2875 2699

電話: +852 2333 6249 傳真: +852 2356 9798

傳真: +853 2875 2661

電郵: repairs@germanpool.com

此保用只適用於香港及澳門

This warranty is valid only in Hong Kong and Macau

# GERMAN

#### German Pool (Hong Kong) Limited

#### Hong Kong

Room 113, Newport Centre Phase II, 116 Ma Tau Kok Road, Tokwawan, Kowloon, Hong Kong

Tel: +852 2773 2888 Fax: +852 2765 8215

#### China

8th, Xinxiang Road, Wusha Industrial Park, Daliang, Shunde, Foshan, Guangdong

Tel: +86 757 2980 8308 Fax: +86 757 2980 8318

#### Macau

3/F, Edificio Industrial Pou Fung, 145 Rua de Francisco Xavier Pereira, Macau

Tel: +853 2875 2699 Fax: +853 2875 2661





















@All rights reserved. Copying, reproducing or using the contents of this manual is not allowed without prior authorization from German Pool, violators will be prosecuted.