

Instantaneous Electric
Water Heater

DEX



歐盟 A 級能源效益認證
EU ENERGY EFFICIENCY CLASS A

Online Warranty Registration



Please read these instructions and warranty information carefully
before use and keep them handy for future reference.



USER MANUAL

請即進行保用登記！

有關保用條款細則，請看本說明書最後一頁。

Please register your warranty information now !

For Warranty Terms & Conditions,
please refer to the last page of this user manual.


Contents

1. Overview	04
2. Safety instructions	05
3. Technical specifications	08
4. Dimensions	09
5. Installation	10
Installation site	10
Mounting accessories	11
Installing the wall bracket	12
Installing connection pieces	13
Installing the appliance	13
6. Direct connection	14
7. Electrical connection	15
Wiring diagram	15
Structural prerequisites	15
Load shedding relay	15
Electrical connection from below	16
Electrical connection from above	17
8. Initial operation	18
Selection of power rating	18
Shower application	19
Reinstallation	19
Lock level	19
Remote control	19
9. Service menu	20
10. Maintenance work	21
Cleaning and replacing the filter strainer	22
Cleaning and replacing the filter strainer if direct connected	23
11. Environment and recycling	23
12. How to use	24
13. Troubleshooting	27

Note: Carefully read the enclosed safety instructions through in full before using the appliance and follow them during use.

1.Overview

When ordering spare parts, please always specify the appliance model and serial number.



2.Safety Instructions

Notice

Please read these instructions carefully before installing or using the appliance! Keep the instructions handy with the appliance for future use!

Part1-11 is intended for the specialist who is responsible for the installation of the appliance. Part2, 12 and 13 are for the end user. The provided manuals correspond to the technical specifications of the appliance.

The latest version of the instructions can be found online at www.germanpool.com.

- Do not use the appliance until it has been correctly installed and unless it is in perfect working order.
- Do not remove the front cover under any circumstances before switching off the mains electrical supply to the unit.
- Never make technical modifications, either to the appliance itself or the electrical leads and water pipes.
- The appliance must be earthed at all times.
- Pay attention to the fact that water temperatures in excess of approx. 43°C are perceived as hot, especially by children, and may cause a feeling of burning. Please note that the fittings and taps may be very hot when the appliance has been in use for some time.
- The appliance is only suitable for domestic use and similar applications inside closed rooms, and must only be used to heat incoming water from the mains supply.
- The appliance must never be exposed to frost.
- The values stated on the rating plate must be observed.
- In case of malfunction, disconnect the fuses immediately. In case of leaks, cut off the mains water supply instantly. Repairs must only be carried out by the customer service department or an authorised professional.
- This appliance can be used by children aged from 3 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

2.Safety Instructions

- If the appliance is factory equipped with a power supply cable, it must be replaced with an original spare cable from the manufacturer in case of damaged by an authorized technician in order to avoid any hazards.
- In accordance with VDE 0700, a circuit breaker with a contact opening gap of at least 3 mm for each pole must be provided on the mains side of the connecting box for appliances with a fixed connection.
- The wall bracket must be secured with the supplied screws and dowels. The appliance must be secured to the wall bracket. The appliance may only be operated if it has been properly mounted on the wall bracket.
- The prescribed nominal pressure stated on the rating plate may not be exceeded at any time.
- The required water resistance may not fall below the value stated on the rating plate at any time. To observe additionally for pressure less installation:
- The water outlet behind the devices must not be blocked, and the water flow must not be restricted.
- The water outlet facilities, such as shower head, jet control and other outlet unit, must be decalcified regularly. Deposits must be removed in regular intervals.
- Only the fittings recommended by the manufacturer may be used.
- If the appliance is exclusively connected to a single shower, only the shower heads recommended by the manufacturer may be used. No other fittings or appliances which decrease the water flow to the shower may be installed.

2.安全守則

注意

安裝及使用本熱水器前請細閱本說明書。妥為保存本說明書。





說明書1-11部分為負責安裝的專業人員必讀內容。第2、12和13部分為使用者必讀內容。本說明書內容與產品的技術規格相一致。

由合格技師負責安裝、初始操作及保養，以確保符合有關安全標準及安裝條例。本公司對未遵照此規定而引致之損失或問題概不負責

本說明書最新版本請查閱www.germanpool.com。

- 熱水器尚未完全穩妥安裝或被確定一切操作正常之前，請勿使用熱水器。
- 任何情況下，在關掉電源前，不能打開面蓋。
- 切勿對本熱水器(包括熱水器機體、電線或水管)作出任何技術性改動。
- 本熱水器必須時刻接地。
- 請注意溫度高於43℃的水會被界定為熱水(對於小童尤甚)，並可引致燙傷。熱水器經使用一段時間後，水喉配件可能會很熱。
- 本熱水器只適宜用於室內不結霜的環境作家居用途，並只適宜將自來水加熱。
- 切勿將本熱水器暴露於結霜的環境中。
- 必須注意銘牌上所標籤之數值。
- 凡在有適當監督下，或已事前獲悉熱水器使用安全說明，並瞭解相關危害的前提下，3歲以上兒童及身體、感官或心理障礙者或經驗及知識不足者，亦可使用本熱水器。禁止兒童隨意操作本熱水器。禁止兒童在未經適當監督的情況下進行清潔與使用者維修保養工作。


3.Technical Specifications

DEX ELECTRONIC MPS®				Model
A #)				Energy efficiency class
18 kW..27 kW (28 A..39 A)				Rated capacity / rated current
18 kW (26 A)	21 kW (30 A)	24 kW (35 A)	27 kW (39 A)	Chosen capacity / current
3~ / PE 380..415 V AC			3~ / PE 400V AC	Electrical connection
4.0 mm²	4.0 mm²	6.0 mm² 2)	6.0 mm²	Min. required cable size 1)
9.2 3)	10.7 3)	12.3 3)	13.8 3)	Hot water (l/min) max. at Δt = 28 K max. at Δt = 38 K
6.8	7.9	9.0 3)	10.2 3)	
0.4 l				Rated volume
Pressure type 1 MPa (10 bar)				Maximum Static Pressure
pressure-resistant / pressureless				Connecting type
Bare wire heating system IES®				Heating system
≥ 1100 Ωcm ≤ 90 mS/m				Required spec. water resistance @ 15 °C Spec. electrical conductivity
≤ 70 °C				Inlet temperature
2.5 – 8.0 l/min 4)				Flow rate to switch on – max. flow rate
0.2 bar at 2.5 l/min 1.3 bar at 9.0 l/min 5)				Pressure loss
20 °C – 60 °C				Temperature choice
G ½"				Water connection
3.70 kg				Weight (when filled with water)
I				VDE class of protection
PA-IX 6762/I				Noise level test certificate
   				Type of protection / safety

#) The declaration complies with the EU regulation No 812/2013
1) Maximum applicable cable size is 10mm².
2) Mixed water.
3) Flow rate limited to achieve optimum temperature rise.
4) Without flow regulator

- Specifications are subject to change without prior notice.
- If there is any inconsistency or ambiguity between the Chinese version and the English version, the English version shall prevail.
- Refer to www.germanpool.com for the most up-to-date version of the User Manual.
- Under normal working conditions, incoming pressure should not exceed 0.6 MPa. Otherwise, a separate pressure control device is necessary. When incoming water pressure exceeds 0.6 MPa, German Pool will not provide any repair service until a pressure control device is installed.

4.Dimensions



5.Installation



Based on the national constitution guidelines a general test certificate concerning the evidence of applicability of noise behaviour is granted.

The following regulations must be observed:

- VDE0100
- EN806
- Installation must comply with all statutory regulations, as well as those of the local electricity and water supply companies.
- The rating plate and technical specifications.
- Only intact and appropriate tools must be used.

Installation site

- Appliance must only be installed in frost-free rooms. Never expose appliance to frost.
- The Appliance must be wall mounted and has to be installed with water connectors downward.
- The appliance complies with protection type IP25 and may therefore be installed in protection zone 1 according to VDE 0100 part 701.
- In order to avoid thermal losses, the distance between the instantaneous water heater and the tapping point should be as small as possible.
- For maintenance work, a shut-off valve should be installed in the supply line. The appliance must be accessible for maintenance work.
- Plastic pipes may only be used if they conform to DIN16893, Series2. The hot water pipes must be thermally insulated.
- The specific resistance of the water must be at least 1100Ω cm at 15 °C. The specific resistance can be asked for with your water distribution company.

5.Installation

RDX



Mounting accessories

For installations under difficult conditions, these mounting accessories are available:

Mounting kit RDX

(Art. no. 34100)


The instant water heater can be installed by means of this mounting kit in the below situations. The power supply cable is coming out of the wall at any place from behind the unit, but the wall has unusual surface conditions, making it difficult for installing the water heater. The power supply cable is coming from elsewhere and has to be connected to the back of the unit.

Extension kit VDX


(Art. no. 34120) – RDX is necessary!

The instant water heater can be installed by means of this extension kit if the water pipes are coming displaced or exchanged out of the wall or if they are coming edgewise on the wall to the unit. The power supply could come out of the wall at any place under the unit or the wiring could be installed surface-mounted.

VDX



UDX



Extension kit UDX

(Art. no. 34110) – RDX is necessary!

The instant water heater can be installed by means of this extension kit if the water-connections are expiring above the unit. The power supply could come out of the wall at any place under the unit or the wiring could be installed surface-mounted.

5.Installation




Installing the wall bracket

Note


If you install this instantaneous water heater in exchange for a conventional instantaneous water heater, there is generally no need to drill holes for the wall bracket, in this case step 2 would not be necessary.

Thoroughly rinse the water supply pipes before installation to remove soiling from the pipes.

1. Using a 12 mm hexagon socket screw key, screw the screw-in nipples into the wall connections. The seals must be fully screwed into the thread. After tightening, the double nipples must protrude by at least 12 mm.
2. Hold the included mounting template on the wall and align it so that the holes in the template fit over the connections. Mark the drill holes according to the template and drill them using a 6mm drill. Insert the included dowels.
3. Screw in the wall bracket. Offset tiling or uneven surfaces can be compensated by up to 30 mm with the aid of the spacers supplied. The spacers are fitted between the wall and the wall bracket.



5.Installation



Installing connection pieces




Note

Fasten the screw nuts with caution, to avoid damage to the valves or the piping system.


1. As shown in the illustration, screw the cold water connection piece with the union nut and the 1/2" seal onto the cold water connection.
2. Screw the hot water connection piece with the union nut and the 1/2" seal onto the hot water connection.

Installing the appliance

1. To open the appliance hood, take off the faceplate and unscrew the main hood screw. When replacing an appliance, the electrical power supply cable may be connected in the upper part. Only in such case, follow the instructions "Electrical connection from above".
2. Place the appliance on the heater bracket so that the threaded rod of the wall bracket fits in the provided hole of the appliance. If necessary, slight corrections are possible by carefully bending the threaded rod of the wall bracket. However, it must be possible to screw on the water connection pipes of the appliance without applying force.
3. Screw the two 3/8" union nuts of the appliance's water connection pipes, each with the 3/8" seal, onto the fittings.
4. Screw the plastic knurled nut onto the threaded rod of the wall bracket.
5. Open the water supply line to the unit and slowly open (position "open") the shut-off valve (a) in the cold water connection piece. Check all connections for leaks.
6. Next, open and close the hot water tapping valve several times until no more air emerges from the line and all air has been eliminated from the instantaneous water heater.



6.Direct Connection



Note

Fasten the screw nuts with caution, to avoid damage to the valves or the piping system.

For direct connection, the two 1/2" screw-in nipples and the 1/2" seals must be screwed into the 1/2" union nuts of the hot-water and cold-water connectors. The two 1/2" caps of the side outlets of the hot-water and cold-water connectors must be removed and screwed onto the open end of the screw-in nipples. The hot-water and cold-water connectors must then be screwed into the 3/8" union nut of the appliance and delivery pipe, together with the 3/8" seals.

For direct connection, it is advisable to mount the appliance at a distance as illustrated alongside, using the spacer sleeves supplied. It should therefore be noted that the two fixing holes near the lower pipe connections are also used.


The flared end of the pipes must be screwed into the 1/2" side outlets of the hot-water and cold-water connectors with 1/2" union nuts and 1/2" seals. The holes required for the pipes must then be broken out

of the housing with the aid of a blunt instrument.

In case of direct connection please note: Put the strainer into the cold water connection!

7. Electrical Connection

Wiring diagram



- 1.Electronic circuitry
- 2.Heating element
- 3.Safety pressure cut-out
- 4.Terminal strip
- 5.Safety thermal cut-out

Only by a specialist!

Please observe:

- VDE 0100
- The installation must comply with current IEC and national local regulations or any particular regulations, specified by the local electricity supply company.
- The rating plate and technical specifications.
- The unit must be earthed!

Structural prerequisites

- The appliance must be installed via a permanent connection. Heater must be earthed!
- The electric wiring should not be injured. After mounting, the wiring must not be direct accessible.
- An all-pole disconnecting device (e.g. via fuses) with a contact opening width of at least 3mm per pole should be provided at the installation end.
- To protect the appliance, a fuse element must be fitted with a tripping current commensurate with the nominal current of the appliance.

Load shedding relay

If further three-phase appliances are connected, a load shedding relay designed for electronic instantaneous water heaters can be connected to phase conductor L₂.

LCD	Description
0	Operation without load shedding relay,manufacturer's setting
1	Operation with normal load shedding relay
2	Operation with sensitive load shedding relay

A special operating mode must be selected on the appliance for this purpose. To change the operating mode, press the four keys (①,②,③and④) simultaneously and wait until the desired mode (0, 1 or 2) is shown on the display, then release the keys. Operating mode 1 must be selected first, thus to check the correct operation of the load shedding relay at low appliance output (35 °C setpoint and low water flow rate). Mode 2 must be selected if the load shedding relay flickers.


7. Electrical Connection



Electrical connection from below


Note

If necessary, the connecting terminal can be displaced to the upper part of the appliance. If you want to do so, please follow the instructions in the next chapter.



Check that the power supply is switched off prior to electrical connection!

1. Dismantle approximately 6 cm off the connecting cable above the wall outlet. With the smaller opening ahead, slide the water splash protection sleeve over the connecting cable so that the sleeve is flush with the wall. This prevents any leaking water from coming into contact with the electrical leads. It must not become damaged! The protection sleeve must be used!
2. Open the control panel rightwards.
3. Strip the cables and plug them in the connecting terminals according to the wiring diagram. The appliance must be earthed.
4. Pull the protective sleeve over the connecting cables until the sleeve fits perfectly in the recess of the intermediate panel. Adjust the water splash protection sleeve as illustrated. Reinsert the control panel and lock it on the heating element.
5. Place the hood on the appliance and screw in the fastening screw. After that you can reinsert the faceplate.




7. Electrical Connection




Electrical connection from above

Switched off prior to electrical connection!

1. Open the prepared breaking point (S) in the upper part of the appliance by pressing with a blunt implement (e.g. screwdriver).
2. Slit the grommet to match the cable size. The opening in the grommet should be slightly smaller than the cross-section of the cable in order to ensure optimum protection against water. Fit the grommet into the opening. The protection grommet must be used!
3. Dismantle the cable roughly 6 cm above the point where it emerges from the wall. Hold the prepared appliance so that you can route the cable into the grommet with the other hand.
4. Place the appliance on the heater bracket so that the threaded rod of the wall bracket fits in the provided hole of the appliance.
5. Open the control panel rightwards.
6. Unscrew the fastening screw of the connecting terminal. Displace the connecting terminal to the upper foot. Affix the connecting terminal again.
7. Strip the cables and plug them in the connecting terminals according to the wiring diagram. The appliance must be earthed.
8. Reinsert the control panel and lock it on the heating element.
9. Place the hood on the appliance and screw in the fastening screw. After that you can reinsert the faceplate.




8. Initial Operation



Multiple Power System MPS®:

The rated capacity (max. power consumption) is 27kW/400V and can be changed internally to 24kW, 21kW or 18kW.



Before making the electrical connection, fill the mains and the appliance with water by carefully opening and closing the hot water tap in order to vent completely.

To ensure a maximum flow, remove any existing aerator from the faucet. Flush the warm and cold water pipes each at least for one minute.

After every draining (e.g. after work on the plumbing system or following repairs to the appliance), the heater must be re-vented in this way before starting it up again.

If the water heater cannot be put into operation, the temperature cut-out or the pressure cut-out may have tripped during transport. If necessary, reset the cut-out.

Selection of power rating


Only by authorised specialist, otherwise lapse of guarantee!

Upon first connection of the appliance to the supply voltage, select the maximum power rating. Only after having set the power rating, the heater provides its standard operation mode.

The maximum allowable power rating at installation site depends on the local situation. It is imperative to observe all data shown in the table "Technical specifications", in particular the required cable size and fuse protection for the electrical connection. Moreover, the electrical installation must comply with the statutory regulations of the respective country and those of the local electricity supply company (Germany: DIN VDE 0100).

1. Switch on the power supply to the appliance. The digital display on the appliance must light up.
2. When switching on the supply voltage for the first time, the value "18" flashes in the display. If not, please follow the below note "Reinstallation".
3. Select the maximum allowable power rating depending on the local situation via the up (▲) and down (▼) arrow keys (18 kW, 21 kW, 24 kW or 27 kW).
4. Press key (I) to confirm the setting. The appliance starts operating.
5. Mark the set power rating on the rating plate.
6. Open the hot water tap. Check the function of the appliance.
7. After having set the maximum allowable power rating, the heating element will be activated after approx. 10-30 sec of continuous water flow.
8. Explain to the user how the instantaneous water heater works and hand over the user manual.
9. Fill in the warranty card and return to German Pool according to the instructions.

8. Initial Operation



Shower application

The water heater's temperature must be limited to 55 °C, if it is connected to a shower. The service menu parameter Temperature Limit ("tL") must be set to a value less or equal 55 °C, in consultation with the customer and the lock level must be activated.

When the device is operated with preheated water, it must be ensured that this temperature is limited to 55 °C as well.

Lock level

The operating mode of the appliance can be restricted.

Activation of the Lock level

1. Disconnect the appliance from the power supply (e.g. by switching off the fuses).
2. Insert the jumper on the power electronics (see picture).
3. Put the appliance into operation again.


Deactivation of the Lock level

1. Disconnect the appliance from the power supply (e.g. by switching off the fuses)
2. Remove jumper
3. Put the appliance into operation again


Reinstallation

In case the appliance will be commissioned again under different installation conditions than during its initial operation, it may be necessary to adapt the maximum power rating.

A temporary short-circuit of the two pins, e.g. with a screwdriver acc. to EN 60900 (see figure), will reset all heater parameters to works setting and lock the heating. Value "18" flashes in the display until the maximum power rating has been selected. This condition will maintain when activating and deactivating the supply voltage.



9. Service menu



Menu item order of "Service menu":

↑	FL	Flow
	PO	Power
	t1	Temp in
	t2	Temp out
	CA	Control value
↓	PL	Power limit
	Er	Diagnostics
	LL	Lock level
↑	nr	Software version
	Ch	Radio channel
	rS	Received strength
	bL	Backlight
	tL	Temperature limit
↓	IL	Signal

The service menu offers an overview of system parameters and is used for diagnostics.

Press key ① and key ② simultaneously for at least 2 seconds to call up the service menu, the display confirms by "FL" and by a flashing point. Using the arrow keys (▲) and (▼), you can switch between the individual menu items.

Press key ① to see the value of the currently selected menu. The value flashes in the display. (The values of some menus can be switched over by using the arrow keys (▲) and (▼).) You will get back to the drop-down-menu when pressing key ① again. With key ② you will get back to the standard display (nominal value). After two minutes without any key stroke the system automatically switches back to the standard display.

Individual menu items as follows:

"FL": Flow
Indication of current flow rate given in l/min.

"Po": Power
Indication of current power consumption (kW).

"t1": Temp in
Indication of inlet temperature (°C).

"t2": Temp out
Indication of outlet temperature (°C).

"CA": Control value
Indication of calibration value of the control system. Regular range: 40 – 60.

"PL": Power limit
Informs about the current maximum power rating (kW) of the appliance.

"Er": Diagnostics
Indication of the last ten diagnostic messages.

The error code is indicated by the first displayed value after pressing key ① (refer to "Abstract for Trouble-Shooting & Diagnostics" in the hood). By using the arrow keys (▲) and (▼) the last 10 error codes are displayed chronologically. Thereby the display indicates in turns the error numbers from "0" to "9" and the corresponding error. The last error will be recorded at position "0" and the former ones each shifted 1 position backwards.

"LL": Lock level
The operating mode of the appliance can be restricted.

Setting Options:

- "0" no restriction (factory setting)
- "1" factory reset via key (countdown) not possible, parameters can be seen, but not be modified in setup menu
- "2" same as "1", additionally the setup menu cannot be opened
- "3" same as "2" additionally nominal value memory 1 and 2 not changeable
- "4" same as "3", additionally nominal value not changeable

Note: When the setting 1, 2, 3 or 4 was chosen, the system parameters can no longer be modified in the service menu.

In order to modify these system parameters, it is necessary to remove the jumper on the power electronics, as specified in the chapter "Deactivation of the lock level".

"nr": Software version
Information about installed software version.

9. Service menu

Menu item order of "Service menu":

↑	FL	Flow
	PO	Power
	t1	Temp in
	t2	Temp out
	CA	Control value
↓	PL	Power limit
	Er	Diagnostics
	LL	Lock level
↑	nr	Software version
	Ch	Radio channel
	rS	Received strength
	bL	Backlight
	tL	Temperature limit
↓	IL	Signal

"Ch": Radio channel
(with wireless module only)
Information about the current radio channel of the water heater and its remote control.

"rS": Received strength
(with wireless module only)
Information about the current signal quality of the remote control as percentage. Depending on the distance between remote control and water heater the value varies between 10 % and 100 %.

"bL": Backlight (optional)
The display illumination can be activated and deactivated.

Setting options:

- »0« Backlight always on
- »1« Backlight switches on automatically, if button is pressed, or water is heated (preset)
- »2« Backlight always off


"tL": Temperature limit

The maximum setable temperature can be reduced to any value within the temperature limit.

The Lock Level must be activated by placing the jumper to enable the limitation.

"IL": Signal
Information about the quality of the radio contact when a diagnostic display is connected.

10. Maintenance work




Maintenance work must only be conducted by an authorised professional.

Cleaning and replacing the filter strainer

The cold water connection of this instantaneous water heater is equipped with an integrated shut-off valve and a strainer. Soiling of the strainer may reduce the warm water output. Clean or replace the strainer as follows:

1. De-energize the instantaneous water heater (e.g. via deactivating the fuses) and prevent inadvertent reactivation of them.
2. To open the hood, take off the small face plate, loose the screw behind this cover and detach the hood.
3. Close the shut-off valve (a) in the cold water connection piece (position “closed”).
4. Unscrew the screw plug (b) from the cold water connection piece and take out the strainer (c).
5. The strainer can now be cleaned or replaced.
6. After fitting of the clean strainer tighten the screw plug.
7. Slowly reopen the shut-off valve in the cold water connection piece (position “open”).
8. Vent the unit by carefully opening and closing the affiliated warm water tap valve several times until air no longer emerges from the pipe.
9. Fit the hood of the unit. Then switch on the voltage again (e.g. via activating the fuses).

10. Maintenance work




Cleaning and replacing the filter strainer if direct connected

The cold water connection of this instantaneous water heater is equipped with a strainer. Soiling of the strainer may reduce the warm water output. Clean or replace the strainer as follows:

1. De-energize the instantaneous water heater (e.g. via deactivating the fuses) and prevent inadvertent reactivation of them.
2. Close the shut-off valve in the mains water supply of the instantaneous water heater.
3. To open the hood, take off the small faceplate, loose the screw behind this cover and detach the hood.
4. Unscrew mains water inlet from connection piece and take out the strainer.
5. The strainer can now be cleaned or replaced.
6. After refitting the clean strainer reconnect the mains water inlet to the connection piece.
7. Slowly reopen the shut-off valve in the mains water supply.
8. Vent the unit by carefully opening and closing the affiliated warm water tap valve several times until air no longer emerges from the pipe.
9. Fit the hood of the unit. Then switch on the voltage again (e.g. via activating the fuses).

11. Environment and recycling



Your product was manufactured from high-quality, reusable materials and components. Please respect in case of discarding that electrical devices should be disposed of separately from household waste at the end of their service life. Therefore, please take this device to a municipal collection point that accepts electronic scrap on a free of charge basis. Disposing it correctly will support environmental protection and will prevent any potential negative effects on human beings and the environment that could arise from inappropriate handling of these devices at the end of their service life. Please contact your local authority for further details of your nearest designated collection point or recycling site. Business customers: If you wish to discard electronic equipment, please contact your dealer or supplier for further information.

12. How to use



As soon as you open the hot water tap, the instantaneous water heater switches on automatically. When the tap is closed, the appliance automatically switches off.

Temperature setting

You can set the required temperature gradually to a lower or higher value with the arrow keys (A) and (V). The temperature changes by 1 °C if key is pressed shortly one time. Pressing a key for a longer time changes the temperature continuously. You can select the outlet temperature from 20 °C to 60 °C.

Note


If temperature is set below 20 °C with arrow key (V) shows “--” and the appliance switches off the heating function.

If the water heater supplies a shower, the maximum temperature was reduced during initial operation. This limitation cannot be exceeded.

Programme buttons


The two programme buttons (1) and (2) allow to quickly select the preset temperature. When pressing a programme key, the preset temperature is selected and displayed. The factory setting for programme (1) is 35 °C and for programme (2) it is 48 °C. You can assign your own settings for the programme keys:

Prolonged pressing of the programme key stores the previously selected temperature. The display changes from “P1” or “P2” to the newly stored temperature value. This newly set temperature is now available to you each time you press the corresponding program key.



Display of new value (e.g. 43 °C)

12. How to use



Temperature limitation



The instantaneous water heater DEX is equipped with an optional temperature limiting function. This scalding protection is deactivated in the factory setting.

Switch on: Select the limit temperature, then press (1) and (A) simultaneously for at least 3 sec. The display briefly confirms the activation by “HI”.

Switch off: press program key (1) and (A) simultaneously for at least 3sec. The display briefly confirms the deactivation by “--”.

Note


By activation of the temperature limit also the programme keys are limited. Therefore, the fixed values of the programme keys may be set again after deactivation of the temperature limitation.



Reset to factory setting

All factory settings can be recalled:

Press (A) and (V) simultaneously. The display now counts backwards from “10” to “00” in second intervals. The appliance is reset at value “00” - if you stop pressing the keys earlier, you will cancel the process.



How to save energy

Set the exact temperature you need on the appliance and open the hot water tap. Once you feel that the water is too hot, do not add any cold water and, instead, enter a lower temperature on the appliance. If you were to add cold water, the water already heated would cool down again and valuable energy would be wasted. Moreover, the cold water added in the tap is not covered by the control range of the electronic circuitry, with the result that temperature constancy is no longer guaranteed.

12. How to use

Power limit



Power limit

If the full output of the instantaneous water heater does not suffice to heat the tapped quantity of water, this will be indicated by the LCD decimal point (e.g. in winter time, when opening several taps at once). When you reduce the hot water flow rate, the LCD point stops indicating because the output of the appliance is again sufficient to reach the set temperature. You can use the full output to fill a bathtub, for instance.

Unit provides no output



Top-up heating

When operating with preheated water (e.g. with solar systems), you must ensure that the inlet temperature does not exceed 70 °C.

If the inlet temperature exceeds the set point, the flashing decimal point of the digital display indicates that the heating power is switched off.

Venting after maintenance work

The instantaneous water heater features an automatic air bubble protection to prevent it from inadvertently running dry. Nevertheless, the appliance must be vented before using it for the first time. Each time the appliance is emptied (e.g. after work on the plumbing system, if there is a risk of frost or following repair work), the appliance must be re-vented before it is used again.

- 1. Disconnect the instantaneous water heater from the mains by deactivating the fuses.
- 2. Unscrew the jet regulator on the outlet fitting and open the cold water tap valve to rinse out the water pipe and avoid contaminating the appliance or the jet regulator.
- 3. Open and close the hot water tap until no more air emerges from the pipe and all air.
- 4. Only then should you reconnect the power supply to the instantaneous water heater and screw the jet regulator back in.
- 5. The appliance activates the heater after approx. 10 seconds of continuous water flow.

Cleaning and maintenance


- Plastic surfaces and fittings should only be wiped with a damp cloth. Do not use abrasive or chlorine-based cleaning agents or solvents.
- For a good water supply, the outlet fittings (special tap aerators and shower heads) should be unscrewed and cleaned at regular intervals. Every three years, the electrical and plumbing components should be inspected by an authorised professional in order to ensure proper functioning and operational safety at all times.

13. Troubleshooting



Repairs must only be carried out by authorised professionals.

If a fault in your appliance cannot be rectified with the aid of this table, please contact the Central Customer Service Department at GERMAN POOL. Please have the details of the typeplate at hand.



Hong Kong Sole Agent
German Pool (Hong Kong) Limited
Room 113, Newport Centre
Phase II, 116 Ma Tau Kok Road,
Tokwawan, Kowloon, Hong Kong
Tel: +852 2773 2888
Fax: +852 2765 8215
Email: info@germanpool.com

The instantaneous water heater was manufactured conscientiously and checked several times before delivery. Should malfunctions nevertheless occur, it is usually only due to a bagatelle. First attempt to switch the house fuses off and on again in order to reset the electronics. Next, try to remedy the problem with reference to the following table. In doing so, you will avoid unnecessary expense of customer service assistance.

Problem	Cause	Solution
Water stays cold, digital display does not light up	Master fuse tripped	Renew or activate fuse
	Safety pressure cut-out tripped	Contact customer service
Water stays cold, digital display lights up	Safety thermal cut-out tripped	Contact customer service
Display flashes error message "Er"	Control system has switched off	Switch fuse off and on. If "Er" still flashes contact customer service
Flow rate of hot water too weak	Outlet fitting dirty or calcified	Clean shower head, jet regulator or sieves
	Fine filter dirty or calcified	Let clean fine filter by customer service
Selected temperature is not reached , decimal point lights up	Water flow rate too high	Reduce water flow rate at the tap
Selected temperature is not reached, decimal point doesn't light up	Cold water has been added via the tap	Tap hot water only; set temperature for use
Decimal point flashes	Inlet temperature exceeding nominal	Reduce inlet temperature
No response upon keypress	Hood is not fitted properly	Refit the hood properly


目錄

1. 概觀圖	29
2. 安全守則	07
3. 規格	30
4. 尺寸	31
5. 安裝	32
安裝地點	33
裝掛配件	34
安裝牆上掛碼	34
安裝接駁配件	35
安裝熱水器	35
6. 直接接駁	36
7. 電線接駁	37
線路圖	37
結構要求	37
電量調校繼電器	37
底部標準電線接駁	38
上面部份電線接駁	39
8. 初步操作	40
功率選擇	40
鎖定等級	41
重新安裝說明	41
遙控器	41
9. 服務功能表	42
10. 保養	44
清洗及更換沙隔	44
直接接駁時清潔並更換濾網	45
11. 環保及再造	45
12. 使用指示	46
13. 檢查要點	48

注意：在使用本產品之前，請仔細閱讀隨附的安全說明，並在使用過程中遵循這些說明。

1.概觀圖

訂購個別零件時，請註明熱水器型號及機身編號。



3.規格

DEX ELECTRONIC MPS®				型號
A #)				能源標籤
18 kW..27 kW (28 A..39 A)				額定功率/ 額定電流
18 kW (26 A)	21 kW (30 A)	24 kW (35 A)	27 kW (39 A)	選擇功率/ 電流
3~ / PE 380..415 V AC			3~ / PE 400V AC	接駁電源
4.0 mm²	4.0 mm²	6.0 mm² 2)	6.0 mm²	最低電線尺寸要求 1)
9.2 3)	10.7 3)	12.3 3)	13.8 3)	最高熱水量(公升/分) Δt = 28 K Δt = 38 K
6.8	7.9	9.0 3)	10.2 3)	
0.4 l				額定容量
Pressure type 1 MPa (10 bar)				額定壓力
開放式/封密式				安裝方式
Bare wire heating system IES®				加熱系統
≥ 1100 Ωcm ≤ 90 mS/m				要求來水電阻@15°C 導電性能
≤ 70 °C				入水水溫
2.5 – 8.0 l/min 4)				要求最低流量至最高流量
0.2 bar at 2.5 l/min 1.3 bar at 9.0 l/min 5)				壓力損失
20 °C – 60 °C				溫度選擇
G ½"				水管接駁
3.70 kg				重量（注水後）
I				VDE安全保護級別
PA-IX 6762/I				嘈音測試憑證
<div><div><div><div></div><div>DE</div></div><div><div></div><div>GS</div></div></div><div><div><div></div><div>VDE</div></div></div><div>IP25</div><div>CE</div></div>				安全認證

#)符合歐盟法規No.812/2013的要求。
1)最大電線尺寸10平方毫米。
2)混合水。
3)限流目的為達到最佳溫度上升效果。
4)不設限流器。


產品規格及設計如有變更，恕不另行通知。

中英文版本如有出入，一概以英文版為準。

本產品使用說明書以 www.germanpool.com 網上版為最新版本。

正常情況下，如供水系統之來水水壓超過0.6 MPa，用戶必須額外加裝減壓器將水壓調低。如來水壓力超過0.6 MPa而用戶未有安裝減壓器，本公司有權拒絕為熱水器進行任何維修。

4.尺寸



5.安裝




安裝時必需遵守下列指示：

- VDE 0100
- EN 806
- 當地有關之電線安裝條例、安全標準、電力供應商或水務署之安全條例。
- 銘牌上的產品規格。
- 必須使用完好和適當的工具。

安裝地點

- 必須安裝於全年都不結霜之房間內。
- 此熱水器只可作掛牆式安裝，出入水接駁喉位向下。
- 根據VDE0100 part701，熱水器的防護等級為IP25，熱水器必須安裝於保護區1內。
- 為避免失溫，應將熱水器安裝於最接近出水位置。
- 為方便保養工作，應在供水喉位置裝上閘掣。熱水器必須處於易於接近的地方。
- 如選用膠喉，該膠喉必須符合DIN16893 Series 2規格。熱水喉必須有保溫保護。
- 來水於15°C時，水電阻最少應為1,100Ωcm。有關詳情可向水務署查詢。

5.安裝



裝掛配件

若所選熱水器安裝地點難以安裝，可選配下列裝掛配件：

裝掛套裝 RDX

(序號：34100)

在下列情況下，此裝掛套裝可以用來安裝熱水器。當安裝牆壁表面不平均，而電源線出線位又正在這表面之上，令熱水器難以安裝。電源線需從其他表面拉到已選安裝位置才能被連接到熱水器的背面。

擴展套件 VDX

(序號：34120) - 必須選用RDX

下列情況下，此擴展套件可以用來安裝熱水器。當水管冷熱水位倒置、水管出牆位置需要改動來迎合熱水器的安裝位置時。電源線從熱水器的下方出牆或電線可作表面安裝。

擴展套件 UDX

(序號：34110) - 必須選用RDX

下列情況下，此擴展套件可以用來安裝熱水器。當水管在熱水器之上方終結時。電源線從熱水器的下方出牆或電線可作表面安裝。

5.安裝




安裝牆上掛碼

注意


如果此即熱式熱水器用以更換傳統形式即熱式熱水器，一般無需於牆上掛碼上鑽孔。在此情況下，無需理會步驟2。

安裝前先徹底清洗供水喉管。

- 1. 用12毫米六角匙將杭牙旋入牆上接駁位置，旋妥杭牙後，杭牙應外露12毫米。
- 2. 將附上的範本放在牆上適當位置以配合冷熱水位置。根據範本位置記下鑽孔位置，用6毫米鑽咀鑽孔，放入合縫釘旋入掛碼。
- 3. 可用附上的水平板碼調校達30毫米之牆面不平或傾斜情況。水平板碼應裝在牆壁與掛碼之間。



5.安裝




安裝接駁配件



注意

旋緊螺母時應小心避免損壞閥或喉管。


- 1. 如圖所示將緊固螺母1/2” 密封圈與冷水進水配件連接。
- 2. 如圖所示將緊固螺母1/2” 密封圈與熱水出水配件連接。



- 1. 旋鬆螺絲，打開面蓋。當更換熱水器時，電源線只可從熱水器上半部接駁，只在此情況下，參考「上面部份電線接駁」。
- 2. 將熱水器掛在掛接背板上，如有需要可略為彎曲螺紋桿。注意，彎曲螺紋桿後旋上進出水配件時應無需使用蠻力。
- 3. 將兩個3/8” 緊固螺母及3/8” 密封圈旋入進出入連接配件內。
- 4. 將膠螺母旋入牆上掛碼螺紋棒上。
- 5. 打開冷水供水喉，慢慢旋開閘掣(a)(位置：開)，查看有否滲漏。
- 6. 接著連續打開及關閉熱水龍頭閥數次將熱水器內的空氣排出。



6.直接接駁



直接接駁

注意

旋緊螺母時應小心避免損壞閥或喉管。

直接接駁時把兩個1/2” 杭牙及1/2” 密封圈旋入冷熱水接駁件的1/2” 緊固螺母內。取出冷熱水接駁件的1/2” 密封帽，然後旋入杭牙的開放一端。將冷水及熱水的接連配件旋入熱水器機身及送水管的3/8” 緊固螺母及3/8” 密封圈。


直接接駁安裝時，應利用附上的水準板，儘量垂直緊貼牆身安裝，可同時利用接駁喉管下半部的固定孔固定位置。

喉管的喇叭接頭必需連1/2” 緊固螺母及1/2” 密封圈旋入冷熱喉的1/2” 接連配件。並在機身外殼底部開孔讓冷熱水喉穿過。

直接接駁時請注意：將沙隔置於冷水入水接駁位!

7.電線接駁

線路圖



- 1. 電子線路
- 2. 發熱元件
- 3. 安全限壓斷電裝置
- 4. 端子板
- 5. 感溫斷電安全裝置

必須由合格技師負責!

請注意：

- VDE 0100
- 必須按現行之IEC標準、當地的電線安全標準及法規、及根據任何當地電力供應商之標準或法規安裝。
- 參照銘牌上註明的技術規格。
- 熱水器必須接駁地線！

結構要求

- 熱水器必須穩固永久接駁安裝。熱水器必須接駁地線！
- 電線不應損壞，安裝後電線不應可以直接觸摸得到。
- 電源開關應為全極式開關（經保險絲），兩極之間應保持最少3毫米距離。
- 應安裝保險絲。

電量調校繼電器

如進一步接駁其他三相電器，可將電量調校繼電器接駁至導電器L2。

LCD顯示	內容
0	無電量調校操作/生產廠方設定
1	以正常電量調校繼電器操作
2	以敏感電量調校繼電器操作

- 如進一步接駁其它三相電器，需選擇特別的操作模式。
- 要更換操作模式，需同時按著4個按鍵(①、②、③、及④)直至要求的模式顯示，然後放開按鍵。首先必需選擇模式1，檢視低電量操作的電量調校繼電器操作正常（35℃設定及低水流量）。如繼電器閃動，需選擇模式2。


7.電線接駁

底部標準電線接駁

注意

如有需要，可將接駁線插移至熱水器上半部，如需這樣做，請參照下一部份指示。

1. 接駁電線前，請必先確定電源已關上。
2. 從牆上插座位元拆除約6厘米電線，套入濺水保護套，使保護套與牆身齊平，確保如有漏水也不會沾濕電線。
3. 打開控制板。
4. 按本頁頂部的線路圖剝去電線外皮並將其接到接線端子上。此熱水器必須連接地線。
5. 將電線的保護套拉上並套入中間層板的凹位，再蓋上中間層板的面板，再用螺絲將電路板蓋面鎖緊。
6. 用螺絲將熱水器面蓋鎖緊。




7.電線接駁


上面部份電線接駁

接駁電線前，請必先確定電源已關上。


1. 用工具(例如螺絲批)按壓預先預備的開孔位置(S)。
2. 介開電線位密封膠蓋，介開的面積應略為少於電線的面積以確保最佳的防水性能。將密封膠蓋套入入線孔。
3. 從牆身電線出線位預留約6厘米電線，將電線經密封膠蓋穿入熱水器內。
4. 將熱水器掛在背碼上，背碼有螺紋的支柱應套入熱水器的孔內。
5. 打開控制面板。
6. 旋鬆電線接駁線插的螺絲，將線插移往上部位置，再接駁線插。
7. 按照線路圖接駁電線，此熱水器必須接駁地線。
8. 裝回控制面板，並將其固定在發熱元件上。
9. 裝回及固定外殼，然後裝回面板。



8.初步操作



多功率調校系統 MPS®:
額定功率（最高能源耗用量）
為27kW/400V，可內部轉換為
24kW、21kW或18kW。



接駁電源前，先將水注入熱水器內，然後開關熱水器龍頭數次，以將熱水器內的空氣排出。

為確保最大流量，需除去水龍頭的起泡器。對熱水管及冷水管分別排水至少1分鐘。

每次維修或水喉工程後，必須將熱水器內的空氣排出，然後再啟動熱水器。

如果熱水器未能啟動，可能因為安全限壓斷電裝置或感溫斷電安全裝置於運輸期間錯誤啟動。如有需要，請先重設有關裝置。

功率選擇


必須由註冊技師調校，否則保養作廢。
初次接駁電源後，選擇最大功率。只在設定功率後，熱水器才進入標準操作模式。
最大可容許功率需視乎安裝地點情況而定。必須注意技術規格表內所提供的資料，特別是電源線的要求及電線接駁的保險絲保護，所有電線接駁安裝必須遵照安裝地點的有關法例（德國：DIN VDE0100）。

1. 開著熱水器後，顯示屏亮。
2. 初次啟動時，數值「18」會在顯示屏上閃動，否則，請細心閱讀「重新安裝說明」。
3. 按上及下箭咀鍵選擇安裝當地所容許之最大功率（18kW、21kW、24kW或27kW）。
4. 按1鍵確認設定，熱水器將開始操作。
5. 在銘牌上註明所設定的功率。
6. 打開熱水龍頭，檢查熱水器性能。
7. 設定最高容許功率後，發熱線會在水流開始10-30秒後啟動。
8. 將使用說明交給客戶，並向客戶解釋熱水器怎樣操作。
9. 初步操作妥當後，請填妥及寄回保用証。

淋浴功能

當熱水器連接花灑，熱水器的最高溫度必須設定為55攝氏度。服務功能表中的最高溫度鎖定必須設置為55攝氏度或更低。根據客戶的要求，功能許可權也必須被啟動。當熱水器使用預熱熱水時，注意預熱熱水最高溫度也必須為55攝氏度。

8.初步操作



鎖定等級


熱水器的操作模式可加以限定。

啟動鎖定等級：

1. 斷開熱水器電源(例如關掉保險絲)。
2. 跳線接通電源。(見圖)
3. 再次運行熱水器。

關閉鎖定等級：


1. 斷掉熱水器電源(例如關掉保險)。
2. 移除跳線。
3. 再次運行熱水器。



重新安裝說明

當熱水器需要與初次安裝情況下有別的狀態下重新安裝，安裝時可能需要設定最大功率。暫時性的兩極短路，例如使用符合EN60900的螺絲批(如圖所示)，會重新設定熱水器的參數。數值「18」會在顯示幕閃動直至熱水器最大功率被用戶選定為止。此情況會在啟動或取消電源電壓時維持。

9.服務功能表



↑	<i>FL</i>	流量
	<i>Po</i>	功率
	<i>t1</i>	進水口溫度
	<i>t2</i>	出水口溫度
	<i>[A</i>	控制值
↓	<i>PL</i>	功率極限
	<i>Er</i>	診斷
	<i>LL</i>	功能許可權
	<i>nr</i>	軟件版本
	<i>[h</i>	無線通道
	<i>rS</i>	接收強度
	<i>bL</i>	顯示器照明
	<i>tL</i>	最高溫度鎖定
	<i>IIC</i>	信號

服務功能表列有系統參數，供診斷期間使用。
同時按下按鍵①和按鍵②至少2秒鐘調校服務菜單，顯示器以「FL」和閃點形式確認啟動。使用方向鍵⬆️和⬆️，您可在功能表項目之間進行切換。

按下按鍵①，觀察當前所選功能表數值。顯示器閃爍數值(可使用按鍵上和下切換至某些功能表的數值)。再次按下按鍵①後可回到下拉功能表。按下按鍵②可回到標準顯示狀態(標稱值)。若兩分鐘內未按下任何按鍵，系統將自動切換回標準顯示狀態。

功能表條目如下：

“FL”：流量
顯示當前流速，單位：升/分鐘。

“Po”：功率
顯示當前功耗 (kW)。

“t1”：進水口溫度
顯示進水口溫度(°C)。

“t2”：出水口溫度
顯示出水口溫度(°C)。

“CA”：控制值
顯示控制系統的校準值。正常範圍：40 - 60。

“PL”：功率極限
顯示熱水器當前最大額定功率 (kW)。

“Er”：診斷
顯示最近十條診斷資訊。
按下按鍵1 後，首次出現的數值顯示錯誤代碼(參見防面蓋上的「故障檢查與診斷概要」)。使用按鍵和可按時間順序顯示最近10條錯誤代碼。顯示器從「0」到「9」依次顯示錯誤號和相應錯誤。最近一次錯誤記錄在「0」位置，以往錯誤每條移動1個位置。

“LL”：功能許可權
可限制熱水器的運行模式。
設置選擇：

「0」無限制(出廠設置)
「1」無法使用按鍵重設出廠值，可觀察到參數，但不可在設置功能表中修改。
「2」與「1」相同。此外，設置功能表無法打開。
「3」與「2」相同。此外，標稱值記憶體1和2不可改變。
「4」與「3」相同。此外，標稱值不可改變。

9.服務功能表

↑	<i>FL</i>	流量
	<i>Po</i>	功率
	<i>t1</i>	進水口溫度
	<i>t2</i>	出水口溫度
	<i>[A</i>	控制值
↓	<i>PL</i>	功率極限
	<i>Er</i>	診斷
	<i>LL</i>	功能許可權
	<i>nr</i>	軟件版本
	<i>[h</i>	無線通道
	<i>rS</i>	接收強度
	<i>bL</i>	顯示器照明
	<i>tL</i>	最高溫度鎖定
	<i>IIC</i>	信號

說明：選擇設置1、2、3或4後，服務功能表中的系統參數將不可修改。

若要修改系統參數，必須去除供電電路的跳線。
「功能許可權取消」部分已說明。

“nr”：軟件版本
關於已安裝軟體版本的資訊。

“Ch”：無線通道
關於熱水器及其遙控器當前無線通道的資訊。

“rs”：信號強度(只適用於無線產品)
根據遙控器與熱水器之間的距離，以百分比顯示信號強度的資訊，該數值在10%至100%之間。


“bL”：顯示器照明 (可選設定)
啟動或停用顯示器背光照明
設置選項：

- 0顯示器照明長開
- 1顯示器照明於按下按鈕或當水被加熱時自動開啟 (預設設定)
- 2顯示器照明長關

“tL”：最高溫度鎖定
使用者可以鎖定熱水器之最高可選溫度，該溫度數值需於熱水器的出水溫度範圍之內。啟動最高溫度鎖定功能時，必須先將熱水器跳線。請參閱安裝手冊啟動此設定。

“IIC”：信號
關於連接診斷顯示器後無線通訊品質的資訊。

10.保養




必須由合格技師負責保養。

清洗及更換沙隔

熱水器的冷水入水接駁位配備有綜合式的閘制及沙隔，沙隔藏有污垢會減低熱水出水量，必須定時清理或更換。步驟如下：

1. 先關掉電源(例如關掉保險絲)以防止電源意外接通。
2. 打開熱水器面蓋。先把面蓋取下，旋出面蓋背面的螺絲，然後卸下面蓋。
3. 關掉冷水入水喉內的閘制(a)（狀態：「關」）。
4. 從冷水喉旋出螺絲塞子(b)，然後取出沙隔(c)。
5. 沙隔可以清洗或更換。
6. 放回濾網後，旋緊螺絲塞子。
7. 慢慢打開閘制（狀態：「開」）。
8. 開關熱水龍頭數次將熱水器內的空氣排出。
9. 裝回面蓋，再連接電源(例如接通保險)。

10.保養




直接接駁時清潔並更換濾網

熱水器的冷水入水接駁位配備有綜合式的閘制及沙隔，沙隔藏有污垢會減低熱水出水量，必須定時清理或更換。步驟如下：

1. 先關掉電源(例如關掉保險絲)以防止電源意外接通。
2. 關掉向熱水器輸水的冷水喉閘制。
3. 打開熱水器面蓋。先把面蓋取下，旋出面蓋背面的螺絲，然後卸下面蓋。
4. 從冷水喉旋出螺絲塞子，然後取出沙隔。
5. 沙隔可以清洗或更換。
6. 放回濾網後，重新把冷水入水管連接到連接件上。
7. 慢慢打開閘制。
8. 開關熱水龍頭數次將熱水器內的空氣排出。
9. 裝回面蓋，再連接電源(例如接通保險絲)。

11. 環保及再造




德國寶注重環保，選用包裝物料方面亦以環保為原則。請妥善處理廢棄物以改善環境。

包裝物料對保護熱水器免於運送途中受損致為重要。選用的物料為環保可循環再用的紙盒，膠袋亦為可循環再用的PE塑料。

塑設備的塑膠元件均標有材料代碼，以便在使用壽命結束時予以回收。如處理得當，這些有用材料可100%循環再用。

電器產品應在其使用壽命完結後與生活垃圾分開處理。請把這件產品棄置到電子廢料回收點。

12. 使用指示



開啟熱水龍頭，熱水器會自動開著，關掉熱水龍頭，熱水器會自動關掉。

調較溫度

可以按⬇️及⬆️鍵調校所需水溫。輕按按鍵一次會調校1°C，按鍵時間較長會每次不斷更改溫度。你可以在20°C至60°C範圍選擇出水水溫。

注意

如用箭咀鍵⬆️設定溫度低於20°C會顯示“--”，熱水器會停止加熱。

如果熱水器供給淋浴室，初始操作時最高溫度將降低。不可超出此限制。

程式按鍵

兩個程式按鍵①和②讓你迅速選擇預先設定的溫度。當按下程式鍵，預設溫度便會顯示。出廠前「1」鍵的設定溫度為35°C，「2」為48°C，你亦可將自己選擇的溫度設定於程式按鍵。

延長按著程式按鍵會儲存選擇的溫度，顯示器由P1轉成P2，再顯示新儲存的溫度值。再按有關程式按鍵時會顯示新設定的溫度。

溫度限制


即熱式熱水器DEX備有可選擇的溫度限制功能，此防燙傷保護在出廠前預設為關閉。

- 開啟：選擇溫度限制，然後同時按①及⬆️鍵最少3秒，顯示屏會顯示「HI」確認啟動。
- 關閉：同時按程式鍵①及⬇️鍵最少3秒，顯示屏會示「--」確認關閉。

注意

啟動溫度限值會對程式鍵構成影響。因此，改變溫度限值後可重新設定程式鍵的固定值。

12. 使用指示



重設至出廠設定

所有出廠設定均可喚回。

同時按⬆️及⬇️鍵，顯示屏會以秒計從「10」至「00」倒數。熱水器重設值為「00」。如太早停止按鍵會取消程序。

如何節省能源

將熱水器調校至所需溫度，然後開啟熱水器龍頭。當感覺水溫過熱時，不要加入冷水，應將溫度調低。如加入冷水，已加熱的水會被冷卻，因而浪費能源。

此外，在水龍頭中添加冷水將造成電子電路控制失效，從而導致無法保證溫度恒定。

電量限制

如熱水器的功率未能將熱水器加熱至所需溫度(例如同時打開多個水龍頭)，LCD會以右邊圖點顯示，當你調低水流量，LCD圖點會熄滅，表示功率已足夠將水加熱至所需溫度。

加熱預熱來水

加熱預熱來水時（如使用太陽能系統），需確保入水溫度不超過70°C。

保養工作後的排氣程序

- 熱水器備有自動氣泡保護功能以防止非故意乾燒情況。但每次熱水器因水喉工程或維修而需排出儲水，必需將熱水器內空氣排出，然後再使用。
1. 關掉電源總掣。
 2. 開啟冷水龍頭清洗水喉以免污染熱水器及水喉配件。
 3. 開啟再關閉熱水掣，直至管內不再排出空氣，使熱水器內空氣完全排出。
 4. 然後再接駁電源。
 5. 十秒的不停水流將啟動熱水器。

12. 使用指示


清潔與保養

- 塑料表面及配件只可用濕布擦拭。請勿使用腐蝕性或含氯元素之清潔劑或溶劑。
- 為確保良好供水，應定期擰開並清洗出水口配件（特別水龍頭及花灑噴頭）。每隔三年，電氣和管道組件應由授權專業人士檢查，以確保正常運作。

13. 檢查要點



必需由合格技師維修。
如參考列表未能處理有關問題，
請聯絡德國寶客戶服務部。



香港總代理
德國寶（香港）有限公司
香港九龍土瓜灣馬頭角道116號
新寶工商中心2期113號室
電話：+852 2773 2888
傳真：+852 2765 8215
電郵：info@germanpool.com

本熱水器出廠前經多次反覆測試,如有故障,一般由小問題引致。首先可嘗試重新開關電源重設電子設定。其次可參考以下列表措施解決問題,這樣可節省不必要的維修費用。

故障	原因	措施
出水為冷水，數字顯示沒有亮著	總電源保險絲跳制	更新或啟動保險絲
	安全限壓斷電裝置跳制	聯絡客戶服務部
電子顯示屏亮；水不熱	感溫斷電安全裝置跳制	聯絡客戶服務部
顯示屏閃動“Er”	控制系統關掉	嘗試關掉然後再開啟保險絲。如Er仍然閃動，請聯絡客戶服務部
熱水流量太弱	過濾網骯髒或鈣化	清洗過濾網
	出水配件骯髒或鈣化	清洗花灑頭沙隔等配件
不能達致所選溫度圖點顯示亮著	出水流量太大	減低出水流量
不能達致選擇溫度，沒有顯示圖點	開著冷水龍頭	只開著熱水龍頭，調校使用水溫
圖點閃亮著	入水水溫高於額定水溫	調低溫水水溫
按鍵沒有反應	面蓋未能正確裝上	重新正確裝上面蓋

如欲獲取更多有關本產品最新資訊，歡迎瀏覽本公司網站。
For additional product information, please visit our website.

www.germanpool.com

Notes

此保用只適用於香港及澳門 | This warranty is valid only in Hong Kong and Macau

此保用只適用於香港及澳門



German Pool (Hong Kong) Limited

Hong Kong, China

Room 113, Newport Centre Phase II, 116 Ma Tau Kok Road, Tokwawan, Kowloon, Hong Kong.

Tel: +852 2773 2888

Fax: +852 2765 8215

Mainland China

8th, Xinxiang Road, Wusha Industrial Park, Daliang, Shunde, Foshan, Guangdong

Tel: +86 757 2980 8308

Fax: +86 757 2980 8318

Macau, China

3/F, Edificio Industrial Pou Fung,

145 Rua de Francisco Xavier Pereira, Macau

Tel: +853 2875 2699

Fax: +853 2875 2661



香港《S MARK》
安全認證



中國塑機/家電行業
十大影響力品牌



CEO非凡品牌大賞



香港優質商號



香港工商業獎



2007
最具潛質
創建品牌企業獎



香港中小企業
最佳拍檔大獎



HONG KONG
CONSUMERS CHOICE
2007
香港消費者推崇品牌



香港《Q 嘜》
優質服務證書



香港名牌十年成就獎
HONG KONG TOP BRAND TEN YEAR
ACHIEVEMENT AWARD

© All rights reserved. Copying, reproducing or using the contents of this manual is not allowed without prior authorization from German Pool, violators will be prosecuted.