GERMAN POOL

PORTABLE AIR PURIFIER

PUP-113



USER MANUAL

Please read these instructions and warranty information carefully before use and keep them handy for future reference.

SAFETY INSTRUCTIONS

- To prevent electric shock, please remove power plug before maintaining or moving the device.
- It is strictly prohibited to rinse the device with water. DO NOT use the device near water source or volatile flammable item to prevent electric shock.
- DO NOT put any object into the power input port, otherwise the device cannot be operated.
- 4. DO NOT put any object into air outlet area to avoid malfunction.
- 5. Please keep the device out of reach of children.
- 6. DO NOT use a wet hand to insert or remove power plug in case of electric shock.
- 7. DO NOT clean the device with any acid-based solutions to avoid damage and electric shock.

PRODUCT STRUCTURE



OPERATION INSTRUCTIONS

- After plugged-in, the device goes into standby mode, the button indicator light and backlight are off, and fan does not work.

 The standard fan does not work.

 The standard fan does not work.
- Touch the On / Off Button once, the device will start to work at high speed, and button indicator and backlight area will light up in gradient colors.
- 3. Touch the On / Off Button again, button indicator light and backlight area will become light blue, and fan switches to low speed mode.
- Touch the On / Off Button of for the third time, the device powers off and goes back into standby.



TROUBLESHOOTING

For some common problems, please refer to table below for troubleshooting. If the problem persists, please contact our Customer Service.

| Abnormal Conditions | Possible Causes | Solution |
|------------------------|---|--|
| Cannot turn on | Power disconnected. | Reconnect USB cable, power supply or power bank. |
| Abnormal noise | Check if there is any foreign matter inside the device. | Gently shake the machine and pour out the foreign matter. |
| | Device is placed on an uneven surface. | Keep the device on a flat surface. |

TECHNICAL SPECIFICATIONS

| Model No. | PUP-113 |
|-------------------|---------------------|
| Voltage | DC 5V |
| Power | <2.5W |
| Air Volume | 15m³/h |
| Product Dimension | (Ø) 65 x (H) 158 mm |
| Net Weight | 0.15kg |
| Gross Weight | 0.42kg |

PUP-113_M_20(1.1)

安全注意事項

- 1. 為防止觸電, 在維修、清潔或移動本產品前 **請先拔下雷源線。**
- 2. 嚴禁用水沖洗本產品。請勿在水源或易燃易 揮發物品附近使用本產品,以防止觸電。
- 3. 請勿在電源線接口插入電源線以外的任何 物品,否則將導致本產品無法正常操作。
- 4. **請勿**將仟何物品放入排氣口,以免發生故障。
- 5. 請將本產品放在兒童接觸不到的地方。
- 6. 請勿用濕手插入或拔下電源線,以防觸電。
- 7. 請勿使用任何酸性溶液清潔本產品,以免造 成損壞和導致觸電。

產品結構



操作説明

- 1. 插入USB電源線後,產品處於待機狀態,開關 按鍵指示燈和背光燈均熄滅,風扇不運作。
- 2. 按開關按鍵 (1) ,風扇以高風速運行,開關 按鍵指示燈和背光區域呈彩色漸變。
- 3. 在高風速狀態下再按開關按鍵(①),開關按 鍵指示燈和背光燈區域變為藍色,風扇 以低風速運行。
- 4. 在低風速狀態下再按開關按鍵(①),產品關 閉電源並進入待機狀態。

觀看操作視頻

故障檢修

常見故障處理方法,請參照表格進行檢查, 無法處理時請與維修中心聯絡。

| 故障情況 | 可能原因 | 排除辦法 |
|-------------|------------------|----------------------|
| 無法開機 | 電源斷開 | 重新連接USB電源線、電源供應或行動電源 |
| 發出不正 常聲音 | 產品內部可能 有雜物 | 輕輕倒出及清除 產品內部的雜物 |
| | 產品未有正確 地放在平面上 | 將產品放置在平 坦表面上 |

技術規格

| 型號 | PUP-113 |
|------|---------------------|
| 電壓 | DC 5V |
| 功率 | <2.5W |
| 風量 | 15m³/h |
| 產品尺寸 | (Ø) 65 x (H) 158 mm |
| 淨重 | 0.15kg |
| 總重量 | 0.42kg |

保用條款

使用下膏年保用(白購買日起計算)。

- 一種方式向本公司登記資料,保用
- 手續方正式生效: 1)填妥本公司網頁內之 保田登記表格 www.eermannool.com warranty
- 2)填妥保用登記卡 郵寄至本公司。



Warranty Terms & Conditions

此保用提供德國寶產品之機件在正常 Under normal operations, the product will gurantee a 1-year full warranty provided by German Pool (effective from the date of purchase).

- * 貴戶須在購機十天內,以下列其中 * This warranty is not valid until customer registration information is received by our Service Centre within 10 days of purchase via one of the following means:
 - www.germannool.com warranty

2) Complete all the fields on the attached Warranty Card and III mail it back to our Customer

will be disqualified for free warranty.

transport and others):

or renairs

plastic parts and accessories:

instructions. This warranty does not apply to: labour costs for on-site installation, check-up, repair,

replacement of parts and other transportation costs;

- damages caused by accidents of any kind (including

operating failures resulted from incorrect voltage.

improper operations and unauthorized installations

purchase invoice is modified by unauthorized party:

product is used for any commercial or industrial

- product is repaired or modified by unauthorized

personnel, or unauthorized parts are installed;

serial number is modified, damaged or removed from

另請填妥以下表格並與正本發票一併保存,以便維修時核對資料。用戶提供之所有 資料必須下確無誤,否則免費保用將會無效

Please fill out the form below. This information and the original purchase invoice will be required for any repairs. Warranty will be invalidated if information provided is found to be inaccurate.

型號 Model No.: PUP-113

機身號碼 Serial No.: ________ 發票號碼 Invoice No.: _

購買商號 Purchased From: 購買日期 Purchase Date:

- 1. 未能出示購買發票正本者,將不獨免費 1. Customer who fails to present original purchase invoice 維修服務。
- 2. 用戶應依照説明書的指示操作。本保用 2. Customer should always follow the operating
- 上門安裝、檢驗、維係或更換零件之
- 人丁以及一切運輸費用;
- 因天然與人為音外終成的塌壞 (包括簿 輸及其他):
- 任何朔顾附件及輔助裝置:
- -電源接合不當、不依説明書而結譯或 疏忽使用本機所引致之損壞。 3. This warranty is invalid if:
- 3. 於下列情況下,用戶之保用資格將被取消
- -購買發票有任何非認可之制改; - 產品被用作商業或工業用途;
- -產品經非認可之技術人員改裝或加裝 任何配件:
- 機身編號被擅自塗改、破壞或刪除。 4. 總代理有權選擇維修或更換配件。

電報: repairs@germanpool.com

- 5. 產品一經被轉讓,其保用即被袒作無效。
 - 5. This warranty will be void if there is any transfer of
- 4. German Pool will, in its discretion, repair or replace any ownership from the original purchaser.

客戶服務及維修中心 Customer Service & Repair Centre

中國澳門 九龍灣放桐道1-3號 澳門俾利喇街145號 容等工業大度3億 電話:+852 2333 6249 電話:+853 2875 2699 Tel: +852 2333 6249

10/E Kowloon Gorlown

Hong Kong, China Macau. China 3/E Edificia Industrial Day Eurot 1-3 Kai Hing Road, Kowloon Bay, 145 Rua de Francisco Xavier Pereir

備直:+852 2356 9798 傅真:+853 2875 2661 Fax: +852 2356 9798 Fax: +853 2875 2661 Email: repairs@germanpool.com

此保用只適用於香港及澳門 This warranty is valid only in Hong Kong and Macau