

GERMAN
POOL

MOSQUITO TRAP & ZAP

MTR-324



USER MANUAL


Please read these instructions and warranty information carefully before use and keep them handy for future reference.

Warnings and Safety Precautions

WARNING!

1. Lamps in this appliance cannot be replaced. Scrap the appliance when the lamps cease to operate.
2. DO NOT touch lamp with bare hands after use, it is hot and may cause burns.
3. People may be hurt and property damaged if the bulb is not used and handled as described in these instructions.
4. DO NOT use near any heat source, steam or around corrosive gases.
5. This product is not compatible with dimmer switches.
6. Keep away from flammables; such as paper, clothing, or any other material that may catch fire.
7. Risk of Electrical Shock: DO NOT place fingers or hands on the lamp, or insert any objects into the lamp when it is powered on.
8. This product is for indoor use only, not suitable for use in barns, stables and similar locations. Lamp is not waterproof.
9. DO NOT touch the voltage wire while the light is turned on.
10. This product is not compatible with HID lamps such as lighting, induction or halogen lamp, which have the mechanism and electric circuit to adjust light.
11. If this product has been altered, warranty will be voided.
12. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
13. Keep this product out of reach of children. Children should be supervised to ensure that they do not play with the appliance.
14.  **Dangerous: high voltage!**

Product Structure



Other accessories: Insecticide-free Mosquito Sticky Trap*1, USB-C Cable*1, Cleaning Brush*1

Operation Instructions

1. Press On/Off Button  once to turn the product on, and the product will run on Vacuum Mode by default. The top mosquito lamp beads and fan turn on, and the lamp beads generate a purple light to attract insects. Vacuum fan will suck the insects into the product.
2. Press On/Off Button  again, and the product will switch to Zap Mode. When insects attracted by the lamp touch the high voltage electric grid, they will instantly be zapped to death.
3. Press On/Off Button  again, both Vacuum Mode and Zap Mode will turn on together, the fan will run and the grid will be electrified.
4. Press On/Off Button  again, the product will turn off.

Note:

- In order to achieve the best effect of mosquito-trapping, please keep product working continuously for more than 48 hours. DO NOT open the mosquito box frequently during this period, so as to prevent the mosquitoes from escaping.
- For best results, close doors and windows when the product is in use; and turn on the product 3 hours before bedtime.
- This product is not developed based on the chemical volatile principle, so it cannot take effect immediately like mosquito repellent incense and other similar products. Please use product with patience.
- Catch rate activity will be higher at night. For best results, it is recommended to keep the product away from competing light source.
- For more effective bug-trapping, place the included insecticide-free mosquito sticky trap on the inner bottom of the mosquito box.
- This product is for indoor use only.
- Use this product with 5V 1A adaptor.
- If an external power supply is used to power this product, it must comply with the following standards and specifications:
Standard: IEC 61558-2-16 compliant / Specification: 5VDC 1A

Cleaning & Maintenance

WARNING!

Turn off the product, unplug the USB-C cable, and discharge the current on the high voltage grid before cleaning and maintenance.

1. Frequent cleaning will prolong the life of this product, ensure fire prevention and provide for more efficient operation.
2. Clean the unit as least once per month. Use a moist cloth to wipe the surface of the product. DO NOT rinse or immerse the product in water.
3. Mosquito box may be detached from the main unit and rinsed with water. After cleaning, air dry completely before reattaching to the main unit.
4. Use the included brush to gently remove any debris on the electric grid.

Technical Specification

Model	MTR-324	UV Wavelength	395 nm
Voltage	DC 5V	Net Weight	410 g
Rated Power	4 W	Charging Cable	USB-C
Electric Current	12-35 mA	Product Dimensions	(H) 240 mm
LED Lamp Power/Type	3 W / SMD2835		(W) 122 mm (D) 122 mm

- Specification is subject to change without prior notice.
- If there is any inconsistency or ambiguity between the English version and the Chinese version, the English version shall prevail.
- Refer to www.germanpool.com for the most update version of the user manual.

Mosquito sticky trap refills can be purchased in-store or online:



保用條款

此保用提供德國寶產品之機件在正常使用下壹年保用(自購買日起計算)。

貴戶須在購機十天內，以下列其中一種方式登記資料，保用手續方正式生效：

- 1) 填妥德國寶VIP手機應用程式
保用登記表 (掃描右方二維碼)
- 2) 填妥本公司網頁保用登記表
www.germanpool.com/warranty
- 1) Visit our VIP App and register online:
(Scan the QR Code on the right)
- 2) Visit our website and register online:
www.germanpool.com/warranty

Warranty Terms & Conditions

Under normal operations, the product will guarantee a 1-year full warranty provided by German Pool (effective from the date of purchase).

This warranty is not valid until customer registration information is received by our Service Centre within 10 days of purchase via one of the following means:



另請填妥以下表格並與正本發票一併保存，以便維修時核對資料。用戶提供之所有資料必須正確無誤，否則免費保用將會無效。

Please fill out the form below. This information and the original purchase invoice will be required for any repairs. Warranty will be invalidated if information provided is found to be inaccurate.

型號 Model No.: MTR-324

發票號碼 Invoice No.: _____ 機身號碼 Serial No.: _____

購買商號 Purchased From: _____ 購買日期 Purchased Date: _____


此保用只適用於香港及澳門
This warranty is valid only in Hong Kong and Macau

警告及注意事項

⚠ 警告！

1. 本產品內的燈具不可更換，如燈具損壞，請將本產品報廢處理。
2. 產品使用期間或使用後，嚴禁用手直接觸摸誘蚊燈部分，以免高溫燙傷。
3. 若燈泡未依本說明使用或操作，可能造成人身傷害或財物損失。
4. 嚴禁在熱源、水流或腐蝕性氣體附近使用本產品。
5. 本產品不適用於調光開關。
6. 嚴禁靠近易燃物品（如紙張、衣物或其他易起火物質）放置。
7. 觸電危險：產品運行期間，嚴禁將手指或任何物體伸入網格內，或觸碰高壓電網。
8. 本產品僅限室內使用；本產品不適用於畜舍、馬房或其他類似場所。本產品的照明燈不防水。
9. 燈具開啟時，嚴禁觸碰高壓電網。
10. 本產品不適用於HID燈具，如電燈、感應燈、鹵素燈等具有調光結構及電路的燈具。
11. 如本產品經人為改裝，保用將自動失效。
12. 本產品不適合由肢體、感官或精神能力較弱，或缺乏使用經驗及知識的人士（包括兒童）單獨使用，除非有負責其安全的人士對其使用本產品進行監督或指導。
13. 本產品必須放置於兒童無法觸及的地方。必須對兒童進行看管，確保他們不會把本產品當作玩具。
14.  **危險：高壓電！**

產品結構



其他配件：無殺蟲劑捕蚊貼*1、毛刷（清潔用）*1、USB-C電源線*1

使用說明

1. 按「開關鍵」啟產品，預設運行吸蚊模式：頂部誘蚊燈及風扇同時開啟，誘蚊燈發出紫光吸引蚊蟲，風扇將蚊蟲吸入機內。
2. 再按「開關鍵」一次，可切換至電擊模式：以紫外線吸引蚊蟲飛入內部高壓電網，透過電擊將蚊蟲殺滅。
3. 再按「開關鍵」一次，同步啟動吸蚊模式及電擊模式，風扇運轉且高壓電網帶電。
4. 再按「開關鍵」一次，關閉產品。

注意：

- 為達到最佳捕蚊效果，建議連續使用48小時或以上，期間請勿經常打開儲蚊盒，以免蚊蟲逃脫。
- 日常捕蚊時，請關閉好門窗；建議睡前3小時開啟本產品。
- 本產品並非採用化學揮發類原理滅蚊，因此不能像蚊香等產品馬上見效，請耐心使用。
- 產品於夜間捕捉效果較佳，建議遠離其他光源以達到最佳誘捕效果。
- 為提升捕蚊效果，請將隨附的無殺蟲劑捕蚊貼放置於儲蚊盒底部。
- 本產品僅限室內使用。
- 請使用5V 1A的電源適配器為本產品供電。
- 如需使用外置電源，必須符合以下標準及規格：
標準：符合IEC 61558-2-16 / 規格：5VDC 1A

清潔與保養

警告！

清潔及保養前必須先關閉產品電源，拔除USB-C電源線，釋放高壓電網上的殘留電流。

1. 定期清潔可延長本產品壽命，降低火災風險，並確保運作效能。
2. 建議至少每月清潔一次，可使用微濕布擦拭產品表面，嚴禁沖洗或將整機浸入水中。
3. 儲蚊盒可拆下並用清水沖洗，清洗後必須待完全風乾，再對準機身扣槽以順時針鎖回原來位置。
4. 使用跟機隨送的毛刷，輕輕清除燈管上的殘留物或灰塵。

技術規格

型號	MTR-324	紫外線波長	395 nm
電壓	DC 5V	淨重	410 g
額定功率	4 W	充電線	USB-C
電流	12-35 mA	產品尺寸	(H) 240 mm
LED燈功率/種類	3 W / SMD2835		(W) 122 mm (D) 122 mm

- 產品規格及設計如有變更，恕不另行通知。
- 中英文版本如有出入，一概以英文版為準。
- 本產品使用說明書以www.germanpool.com網上版為最新版本。

無殺蟲劑捕蚊貼補充裝可於
德國寶陳列中心或eStore購買：

